



Keyboard Operating Quick Start Guide

Keyboard Appearance

The keyboard appearance is shown as below. See Figure Error! No text of specified style in document.-1.




Figure Error! No text of specified style in document.-1

- ① Function key: There are three function keys: SETUP/ALARM/SHIFT
- ② LCD: Displays On Screen Menu.
- ③ Indication light: There are six indication lights. DVR/DOME/ALT/COM/ALARM/POWER.
- ④ DVR function: Operation keys for you to control DVR.
- ⑤ Public function: Tten numeral keys, four direction keys, ESC/ENTER and ID/CAM.
- ⑥ Dome matrix function: Operation keys for you to control dome or matrix.
- ⑦ Joystick
- ⑧ Assistant function: from AUX1 to AUX 6, log and lock key.

Key Function List

| Serial number | Name | Symbol | Function |
|------------------|--------------------------|--------|--|
| Function key | Setup | SETUP | Shortcut key to enter function setup menu |
| | Alarm | ALARM | Shortcut key to enter alarm setup menu |
| | Shift | SHIFT | Switch between input methods |
| LCD | Liquid crystal displayer | | Display on-screen menu |
| Indication light | DVR indication light | DVR | Light turns on when connected with DVR |
| | Dome indication light | DOME | Light turns on when connected with dome |
| | Other | ALT | Light turns on when connected with other devices |

| | | | |
|---|------------------------------|-------|---|
| | indication light | | |
| | Serial port indication light | COM | Light turns on when connected with serial port device |
| | Alarm indication light | ALARM | Light turns on when connected with alarm devices |
| | Power indication light | POWER | Light turns on when keyboard connected with power and works properly. |
| DVR function key | Assistant function key | Fn1 | In single surveillance mode, click Fn1 to display PTZ and image color setup menu. |
| | | | In motion detection setup, working with other keys |
| | | | When playback, click Fn1 to display or hide process bar. |
| | DVR assistant function key 2 | Fn2 | In DVR menu, click Fn2 to select an input method. |
| | Tour | ↻ | Activate tour function |
| | Single window display mode | □ | Single window display mode |
| | Four window display mode | 田 | Turn to four window display mode |
| | Nine window display mode | 田田 | Turn to nine window display mode |
| | Sixteen window display mode | 田田田田 | Turn to sixteen window display mode |
| | Record | ● | Record/play |
| | Backward /Pause | ⏮ / ⏪ | Video backward play or pause |
| | Play frame by frame | → | Play video frame by frame |
| | Play/Pause | ▶⏮ | Play/pause |
| | | | When DVR is in real-time surveillance mode, system goes to video search menu,. |
| | Fast backward | ⏮ | Fast backward playback |
| | Slow play | ▶ | Various slow play speeds |
| | Fast forward | ▶▶ | Various fast play speeds |
| | Previous | ⏮ | Play the previous video |
| | Next | ▶▶ | Play next video |
| | Reverse play frame by frame | ← | Reverse play frame by frame |
| Public function | Character and numerals | 0-9 | Switch between numeral/characters, click Shift to switch. |
| | Device ID | ID | Shortcut key to go to ID control point search |
| | Device channel number | CAM | Control DVR channel. |
| | Cancel | ESC | Cancel current operation |
| In playback mode, click this key to go back to dynamic surveillance mode. | | | |

| | | | |
|---------------------------------|-------------------|--------------------|--|
| | Confirm | ENTER | Confirm current operation |
| | Direction ke | ↑ up ↓ down | In single surveillance mode, click up/down to switch between various channels. |
| | | | Modify numeral |
| | | | Modify setup |
| | | PTZ control switch | |
| | | ← left → right | In dynamic surveillance mode, click left/right key to switch between single window display and multiple window display mode. |
| | | | PTZ control switch |
| Dome/ Matrix key function | Previous pa | PREV | In dome menu, working with other keys. |
| | Dome menu | MENU | In dome menu, click this key to enter dome menu shortcut key. |
| | Next page | NEXT | In dome menu, working with other keys. |
| | Scan | SCAN | System pops up scan menu |
| | Tour | AUTO-PAN | System pops up auto tour menu |
| | Pattern | PATTERN | System pops up pattern menu |
| | Set preset | SET | System pops up preset setup menu |
| | GOTO pres | GOTO | System pops up go to preset menu |
| | Remove preset | REMOVE | System pops up delete preset menu |
| | Iris zoom in | TELE | PTZ iris zooms in |
| | PTZ | P/T | PTZ operation shortcut key |
| | Iris zoom out | WIDE | PTZ iris zooms out |
| | Focus zoom in | NEAR | PTZ focus zooms in |
| | Wiper | WIPER | Shortcut key to control dome wiper operation |
| | Focus zoom out | FAR | PTZ focus zooms out |
| | Lens zoom out | CLOSE | PTZ lens zoom out |
| | Lens zoom in | OPEN | PTZ lens zoom in |
| Light | LIGHT | Control dome light | |
| | Joystick | | Assistant menu and function key operation. |
| Assistant function key | AUX1----- AUX6 | | Assistant key |
| | LOG | LOG | Shortcut key to search log files |
| | LOCK | LOCK | Shortcut key to lock keyboard |

Keyboard Operation

Login

Before you login, please log off from DVR, local user priority is higher than the keyboard user.

Press ID Button, and use Left & Right Arrows until User Name: SHPS appears and enter password.

User ID Is: 0, Press enter

System will automatically begin login if information is correct.

Logout

Click ID key and then click ESC, you can logout current control menu.

PTZ Control and Image Color

In single window click P/T followed by CAM & the camera you are wanting to control.

The keyboard will go to DVR control menu; you can now use the Joy Stick to control the camera.

PTZ movement direction

- For joystick: up/down/left/right/up left/right down/up right/left down.
- For keyboard: up/down/left/right

Zoom/focus/Iris

- Zoom: please use WIDE and TELE to control PTZ zoom.
- Focus: please use FAR and NEAR to control PTZ focus.
- Iris: Please use CLOSE and OPEN to control PTZ aperture.

You can use joystick to control lens, clockwise is to zoom out and anti-clockwise is to zoom in.